





## Control Type and Size Considerations



### Depth Requirements for Inside Mount

Shade Type	Cordless Lift Shades Headrail Dimensions (inches)	 Partially recessed headrail in window casing/molding Minimum Depth Mount (inches)	 Fully recessed headrail in window casing/molding Flush with Casing (inches)
1" Pleat	1 <sup>1</sup> / <sub>16</sub> x 2 <sup>1</sup> / <sub>16</sub>	5/8	2 <sup>3</sup> / <sub>16</sub>
2" Pleat	1 <sup>1</sup> / <sub>16</sub> x 2 <sup>3</sup> / <sub>16</sub>	5/8	2 <sup>3</sup> / <sub>16</sub>

### Depth Requirements for Inside Mount Continuous-Loop Lift

Shade Type	Headrail Dimensions (inches)	 Partially recessed headrail in window casing/molding Minimum Depth Mount (inches)	 Fully recessed headrail in window casing/molding Flush with Casing (inches)
1" Pleat	1 <sup>1</sup> / <sub>16</sub> x 2 <sup>1</sup> / <sub>16</sub>	5/8	2 <sup>3</sup> / <sub>16</sub>
2" Pleat	1 <sup>1</sup> / <sub>16</sub> x 2 <sup>3</sup> / <sub>16</sub>	5/8	2 <sup>3</sup> / <sub>16</sub>

### Depth Requirements for Inside Mount Cordless Lift

Shade Type	Headrail Dimensions (inches)	 Partially recessed headrail in window casing/molding Minimum Depth Mount (inches)	 Fully recessed headrail in window casing/molding Flush with Casing (inches)
1" Pleat	1 <sup>1</sup> / <sub>16</sub> x 2 <sup>1</sup> / <sub>16</sub>	5/8	2 <sup>3</sup> / <sub>16</sub>
2" Pleat	1 <sup>1</sup> / <sub>16</sub> x 2 <sup>3</sup> / <sub>16</sub>	5/8	2 <sup>3</sup> / <sub>16</sub>

<sup>†</sup>For all inside mount applications, 3/8" deduction is taken by manufacturer on overall width.

**NOTE:** Maximum area for 1" Aberdeen, Debonair, Sahara Ridge and Terrain is 6400 square inches; 2" Debonair and Prescott is 5800 square inches; 2" Marina and Sahara Ridge is 7000 square inches, 2" Aberdeen, Cloud Metal and Terrain is 7600 square inches.